

Hawk A Model A Ford Club

Tool Listing

Tool Description	Tool Use
Growler 120 V	Armature Testing
Floor Crane	Engine Hoist
Drill Gauge	Check Drill Size
Door Handle Pin	Remove/Install Door Handle Pins
Distributor Point Drill Template	Modern Points Drill Template
Torque wrench, 30 In-lb. max.	Rear Axle Bearing Preload
Wrench, Pinion Nut, Short	Rear Axle Pinion Nut Torque
Wrench, Pinion Nut, Long, A-4634-T	Rear Axle Pinion Nut Torque
Frame Spreader, A-5091	Spread frame to install engine
Engine stand adapter , A-6005-ADP	Mount engine block to stand
Wrench, pinion, A-4634-T	Rear Axle pinion nut
Head nut torque adapter, A-6064-T	Torque nut at distributor
Head Puller kit, A-6010-PX	Pulling head off block
Puller Rear Hub (Large), Snap on	Remove Hub From Rear Axle
Puller Rear Hub (Small)	Remove Hub From Rear Axle
Puller, pinion, A-4210-X	Rear axle pinion remove/install
Gas Gauge Wrenches ,A-9300	Remove/install Gas Gauge
Front Hub Bearing Race, A-1218	Seats Bearing Cups in Front Hub
Drill Bit 14.5MM	Spring Shackle Repair
Door Hinge Pin Tool, V46335PULL	Remove/Install Hinge Pins
Spring Spreader--Front, A-5301	Remove front spring
Spring Spreader-- Rear, A-5302	Remove rear spring
Knock-Off Puller 5/8-18NF, A-8600-KO	Rear Axle, Steering Wheel
Camshaft Nut Wrench, A-6251	Camshaft Nut Install/Remove
Heli-coil Kit, 7/16-20NF	Steering Sector Housing Repair
Heli-coil Kit, 7/16-14	Block Threads for Head Studs
Drill bit, 29/64" cobalt	Heli-coil Drill for 7/16 studs
Drill Bit, 33/64"	Steering Shaft Repair
Drill Guide, A-6063	Drilling block stud holes
Tap, 9/16-18NF	Steering Shaft Repair
Rivet Set Tool, Homemade	Sets Larger Rivets
Slide Hammer - Large	Steering Worm Removing Tool
Slide Hammer - Small	Steering Worm Removing Tool
Shifter Spring Tool, Tube type	Install/Remove Trans Tower Spring
Shifter Spring Tool, A-7226-T	Install/Remove Trans Tower Spring

Hawk A Model A Ford Club

Tool Listing

Tool Description	Tool Use
Brake Rivet Tool Set, A-2018-T	Install/Remove Brake lining rivets
Brake Shoe Centering, A-2020	Brake shoe centering
Brake Shoe tool	Brake shoe Installation
Carb gas/float level	Check Fuel float setting
Carb Kit #45 Drill Bit (0.082)	Carb Bowl Vent Drill Bit
Carb Kit #60 Drill Bit (0.040)	Carb Jet Drill Bit
Carb Kit #61 Drill Bit (0.039)	Carb Jet Drill Bit
Carb Kit #L Drill Bit (0.290)	Carb Throttle Shaft Drill Bit
Carb Kit Reamer (0.296)	Carb Throttle Shaft Reamer
Carb Venturi, 1.178" x 1.386" x 3"	Venturi Removal Tool
Aluminum Block	Carburetor Throttle Shaft Repair
Light Switch Spider, A-2643-T	Install/remove spider on horn rod
Rear engine main cap nut	torque rear main nut
Reamer , 1/2" A-12132-R	Distributor Bushings
Reamer, 0.559" A-2082-R	Front Brake Operating Shaft
Reamer, 13/16" (0.8125"x 9" long)	Spindle Bushings
Reamer, 13/16" (0.8140")	Spindle Bushings
Reamer, 0.875" x 10"	Pedal Bushings
Reamer Adjustable 27/32 -15/16	Parking Brake Lever
Reamer, 3/4" (0.7500")	Starter End Plate Bushings
Reamer, 1-1/8"	Steering Sector Bushing
Reamer, 11/16" (0.6875), A-2227-R	Rear Brake Camshaft Bushing
Reamer, Spring Bushing, A-5303-R	Shackle Bushings
Driver, oil Pump Bushing (0.485)	Oil Pump Bushings
Driver 0.805 x 6"	Spindle Bushings
Driver, 1.120"	Steering Sector Bushings
Driver, 0.875"	Brake Pedal Bushings
Driver, 0.485"	Distributor Bushings
Driver, 0.653"	Unknown
Driver, Modern Zerks, A-353020-M	Install modern press-in grease zerk
Driver, Original Zerk, A-353020	Install original press-in grease zerk
Wheel Spoke Tool Set A-1016-T	Spoke Straightening TOOLS (2)
Swedge cutting, 1/2"	Cut swedges on wheel hub studs
Spokes, Wheel, A-1016-TX	Straighten Steel Wheel Spokes, Missing
Spokes, Wheel, A-1016-T	Straighten Steel Wheel Spokes